


# Customer Support Services PARTS MANUAL [Fey 22 Oct 2007]

# **Contents**

EXPLODED ASSEMBLY	3
LCD COMPONENTS	4
CONSOLE SUPPORT MOUNTING HARDWARE	5
STAIR CLIMBER MOUNTING HARDWARE	8
CROSS-TRAINER (BLACK) MOUNTING HARDWARE	7
CROSS-TRAINER (SILVER) MOUNTING HARDWARE	8
TREADMILL (BLACK) MOUNTING HARDWARE	9
TREADMILL (SILVER) MOUNTING HARDWARE	10

# **Exploded Assembly**


LCD\_-0\_ \_ -01



OPERATORS MANUAL ENG	M051-00K32-A003
PARTS DESCRIPTION	PART NUMBERS
LINE-CORD: 125V; 10A; DOMESTIC B	0017-00003-0963
POWER-SUPPLY: AC-TO-DC; 12V 6' CORD	0017-00003-0967
POWER-SUPPLY: AC-TO-DC; 12V 10' CORD	0017-00003-0970
LINE-CORD: 250V; 10A; EUROPEAN B	0017-00003-0964
LINE-CORD: 250V; 10A; BRITISH B	0017-00003-0965
LINE-CORD: 250V;10A; AUSTRALIAN B	0017-00003-0966
COAX CBL-ASSY	AK32-00020-0002


# **LCD Components**

LCD -0 -01




# Upright and Recumbent Bikes Mounting Hardware

LCDC\_-0\_ \_ \_-01 LCDR\_-0\_ -01




# Stair Climber Mounting Hardware

LCDS90-0\_ \_ \_-01



# Cross-Trainer (Black) Mounting Hardware


LCD\_ \_-010\_-01




# Cross-Trainer (Silver) Mounting Hardware

LCD\_ \_-020\_-01

0K62-01265-0000 BRKT: REMOTE; 93X/95Xi B



# Treadmill (Black) Mounting Hardware



# Treadmill (Silver) Mounting Hardware

LCDT\_ \_-020\_-01

